



NOTE

FOR COMPRESSORS 1-7
SET SWITCH 1 TO POSITION 1
FOR COMPRESSORS 8-10
SET SWITCH 1 TO POSITION 2

NOTES

1. INPUT STATES ARE AS FOLLOWS:-
CLOSED CONTACT = READY TO RUN
OPEN CONTACT = FAULT
2. CON3 TERMINAL 9 MUST HAVE
NEUTRAL CONNECTED TO IT.
3. TO ENSURE THAT INTERNALLY FITTED
SUPPRESSORS WORK CORRECTLY, CONNECT
LINE VOLTAGES TO TERMINALS PREFIXED
'LN' AND THE CORRESPONDING LOADS TO
TERMINALS PREFIXED 'LD'.
4. SWITCH SETTINGS
THE POSITION OF THE DIP SWITCHES 'SW2'
MUST BE SET AS SHOWN (IE. DOT SHOWING
CLOSED CONTACT ON TWO RIGHT HAND)
FOR THE CARD TO OPERATE CORRECTLY.

SWITCHES 'SW3' CONTROL THE OUTPUT
RELAYS IF PACK SERIAL DATA BUS
COMMUNICATIONS FAIL. (CLOSED 'DOT
SHOWING' = RELAY ENERGISED).



JTL SYSTEMS LTD.
41 KINGFISHER COURT, HAMBRIDGE RD,
NEWBURY, BERKSHIRE, RG14 5SJ
TEL: 01635-263646 FAX: 01635-263647

ISS	DESCRIPTION	APP'D	DATE
1	ADDED NEW PRODUCT EPLT	MJK	4/02
1	ORIGINAL ISSUE	MJK	9/96

TITLE: COMPRESSOR INTERFACE WIRING
(FOR CPLT & EPLT CONTROLLERS)

TYPE: IF-1

PROJ.	DRG No.	SHT	OF	ISS
CP	01859	1	1	2

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP