



IMPORTANT NOTE:

1. TO ENSURE THAT INTERNALLY FITTED SUPPRESSORS WORK CORRECTLY:-
ENSURE THAT LINE VOLTAGE IS CONNECTED TO TERMINALS LN1 - LN4
AND EACH LOAD IS CONNECTED TO THE CORRESPONDING TERMINAL LD1 - LD4.
2. CON-3 IS A VOLT-FREE INPUT. NO EXTERNAL VOLTAGE IS TO BE
APPLIED TO IT TO AVOID EQUIPMENT DAMAGE.
3. THE DEFROST OUTPUT IS USED AS FOLLOWS:-
RCCT - ELECTRIC DEFROST HEATER
RCCS - DEFROST TERMINATION OR HEATER CONTROL
(REFER TO OPERATING MANUAL FOR DETAILS)

		JTL SYSTEMS LTD.	
		41 KINGFISHER COURT, HAMBRIDGE RD, NEWBURY, BERKSHIRE. RG14 5SJ TEL: 01635-263646 FAX: 01635-263647	
ISSUE	DESCRIPTION	APP'D	DATE
2	RCCS ADDED <WAS DRG 00110>	NMT	7-'91
1	ORIGINAL ISSUE	NMT	2-'91
TITLE: DEFROST COLDSTORE CONTROLLER WIRING			
TYPE: RCCT (RCCK), RCCS			
PROJ.	DRG No	SHT OF	ISS
RC	00321	1 1	2