



OUTPUTS &  
INPUTS




EMC INTEGRITY  
DO NOT DRILL HOLES IN THE BOX.  
TERMINATE ALL CABLES OUTSIDE BOX.


PRESSURE TRANS



COMMS



TEMP SENSORS



CONNECTIONS FOR USE WITH CPSA

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

DOC 01895 ISS 2 Mar 1997