



NOTES:

- TO ENSURE THAT THE INTERNALLY FITTED SUPPRESSOR CORRECTLY:-
ENSURE THAT THE LINE VOLTAGE IS CONNECTED TO TERMINALS LD1 = N01
AND EACH LOAD IS CONNECTED TO THE CORRESPONDING TERMINAL LD2 = N02
- INPUTS IP1 AND IP2 ARE VOLT-FREE INPUTS POWERED INTERNALLY FROM THE
MAINS SUPPLY. NO EXTERNAL VOLTAGE IS TO BE APPLIED TO THEM TO AVOID
EQUIPMENT DAMAGE.
- INPUT STATES ARE AS FOLLOWS:-
IP1 - CLOSED CONTACT = AUTO CONTROL (OPEN CONTACT = PLANT FAIL)
IP2 - CLOSED CONTACT = LIQUID LEVEL OK
- FOR LEGACY SYSTEMS CONNECT A FOUR WIRE MULTICORE CABLE TO THE FOUR WIRE
CONNECTOR INTERFACE PIN 1 TO PIN 1 ETC.
FOR 2 WIRE PLANT ZONE UNITS TYPE IF3x USE CABLE CAB72 LINK TERMINALS 1 TO 3 TO RED
& TERMINALS 2 & 4 TO GREEN.

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

JTL SYSTEMS LTD
41 KINGFISHER COURT, HAMBRIDGE RD,
NEWBURY, BERKSHIRE: RG14 5SJ
TEL: 01635 263646 FAX: 01635 263647

ISSUE	DESCRIPTION	APP'D	DATE
3	UPDATED NOTE 4	MJK	10/10
2	ADDED NOTE 4	MJK	10/09
1	ORIGINAL ISSUE	MJK	02/09

TITLE:
**EPID DUAL SUCTION
PACK CONTROLLER WIRING**

PROJ.	DRG No: 03513	SHT	OF	ISS.
		1	1	3