

| JTL FIRMWARE VARIATIONS | | IF14 |
|--------------------------------|--|-------------|
| VERSION | DESCRIPTION | DATE |
| v0.00.0 | Original issue. | June 2002 |
| v1.00.1 | Code added to support analogue output. | Nov 2002 |
| v1.00.2 | Added item 35 for backup value in analogue output mode. | Feb 2003 |
| v1.00.3 | Enabled mode 3 to allow analogue and digital outputs at the same time. Secondary address for relay control added. | June 2007 |
| v1.00.4 | Improved backup operation when running in mode 3. | April 2008 |
| v1.00.5 | Operation corrected when used in IF11 emulation mode. | July 2008 |
| v1.00.6 | Item 34 extended to drive 0 - 10 V in 99 steps for condenser control in legacy pack controllers. | June 2009 |