

<b>JTL FIRMWARE VARIATIONS</b>		<b>EPID</b>
<b>VERSION</b>	<b>DESCRIPTION</b>	<b>DATE</b>
v0.00.0	Initial Release	Mar 2008
v0.00.1	Compressor 6 drive error corrected. Inverter integral limits allows negative value. Inverter suction line allocation default changed to HT. Inverter pressure error added on item 347.	Mar 2008
v0.00.2	Compressor output configuration choice added on 167 to allow compressors 1 and 3 to have 50% unloader Compressor output status extended on item 115-118 to enable remote terminals to display useful information with output configuration use. Low suction pressure safely shutdown introduced on items 195 & 196. Inverter disabled when compressor 1 selected as a 2 stage machine using item 167. Compressor / condenser display operation corrected. Compressor fault repeat alarm feature added using item 158.	Apr 2008