
COLDSTORE DISPLAY



TEMPERATURE AND ALARM

Displays the temperature during normal refrigeration and dEF or dEFr during defrost recovery, alternating with the most serious current alarm. During power up, the display will show 'JTL'.

FUNCTION BUTTON

Select function mode.

SCROLL BUTTON

Press this button to scroll through the list of "functions". The data is preceded by indentification text. If the Scroll button is not pressed the display will automatically scroll to the end of the list at which time the display will resort to temperature and alarm mode.

NOTE:

For full details of text, data and alarms that can be displayed see the item number data for the appropriate product.

THIS IS AN UNCONTROLLED COPY — UNLESS STAMPED WITH CONTROLLED COPY STAMP

JTL HELPDESK NO. 07010 701011



JTL SYSTEMS LTD.
41 KINGFISHER COURT, NEWBURY,
BERKS, RG14 5SJ

Document No: 01852

ISSUE 1