

NG110 NEXT GATEWAY ALARM DISPLAY


ALARM DISPLAY

Displays the most serious unaccepted alarms by cycling the display through the Unit Number and the Alarm Description.

If there are no current active alarms, the display will show '--'.

SIREN

The SIREN sounds when a new alarm condition has been present on the system for a short period. It is recommended to use the 'scroll' button to check the ENTIRE list of alarms each time the siren sounds.



FUNCTION

Press this button to mute the siren (if allowed) and to scroll through the list of displayed alarms.

SCROLL

Press this button to enter Case Cleaning Mode (if allowed). The display will then alternate between 'turn' and 'off' until the Cleaning start period expires.

ENTER
Unused.



JTL SYSTEMS LTD.
41 KINGFISHER COURT,
NEWBURY, BERKS. RG14 5SJ

JTL HELPDESK NO. 07010 701011

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

Document No: 02165

ISSUE 1