



* NOTE RUN LOW VOLTAGE WIRING IN MULTICORE KEEP SEPARATE FROM POWER WIRING.

NOTE PHASING AND CT POLARITY MUST BE CORRECT INCLUDING DIRECTION OF PRIMARY FLOW THROUGH THE CT.

NOTE DO NOT DISCONNECT CT WIRING WITH POWER ON. USE CT SHORTING BARS IF NECESSARY.

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

JTL SYSTEMS LTD
 41 KINGFISHER COURT, HAMBRIDGE RD,
 NEWBURY, BERKSHIRE. RG14 5SJ
 TEL: 01635 263646 FAX: 01635 263647

ISSUE	DESCRIPTION	APP'D	DATE
1	ORIGINAL ISSUE	MJK	11/10

TITLE: **ENERGY METER (kWh) WIRING
3 PHASE UNBALANCED (4 WIRE)**

TYPE: EMF7FTU/PR220

PROJ.	DRG No: 03763	SHT	OF	ISS.
		1	1	1