

CONTENTS

1. Jnet NETWORK IDENTIFICATION 1
 2. CHANNEL SELECTION 1
 3. CHANNEL READINGS AND CALIBRATION DATA 1
 4. CHANNEL ALARM DATA 2
 5. RESTORE FACTORY DEFAULTS 2
 6. SYSTEM ALARMS 2
 6.1 COMMON ALARMS 2
 6.2 CHANNEL ALARMS 2
 7. DIAGNOSTIC & TEST FUNCTIONS 2

JTL ANALOGUE INPUT MONITOR ITEM NUMBERS					AI210		
ITEM	DESCRIPTION		CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
					4321		
1. Jnet NETWORK IDENTIFICATION							
0	Unit type		AI21	Unit type			
19	Software version number						
101	Ch.1	Channel unit number				0.1 - 899.9	
201	Ch.2						
301	Ch.3						
401	Ch.4						
2. CHANNEL SELECTION							
105	Ch.1	Channel selection	OFF C'c'.En	Off Channel 'c' enabled		0 - 1	Enabled
205	Ch.2						
305	Ch.3						
405	Ch.4						
3. CHANNEL READINGS AND CALIBRATION DATA							
A general form of item number is shown below. The "c" shown in each item number should be replaced by the channel number (1-4). This sequence covers item numbers (101 -499) for channels 1 - 4.							
21 (121)	Ch.1	Scaled reading					
22 (221)	Ch.2						
23 (321)	Ch.3						
24 (421)	Ch.4						
c22	Full Scale input calibration					-99.9 to 999.9	100.0
c23	Zero input reading calibration					-99.9 to 999.9	0.0
c24	Unscaled reading						

JTL ANALOGUE INPUT MONITOR ITEM NUMBERS					AI210	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
4. CHANNEL ALARM DATA						
A general form of item number is shown below. The "c" shown in each item number should be replaced by the channel number (1-4). This sequence covers item numbers (101 -499) for channels 1 - 4.						
c30	High alarm level				-99.9 to 999.9	100.0
c31	Low alarm level				-99.9 to 999.9	0.0
c32	Alarm Hysterisis				0.0 to 9.9	1.0
c33	Alarm delay				00:00 to 01:00	00:05
5. RESTORE FACTORY DEFAULTS						
9	Set default values				0 - 1	
. SYSTEM ALARMS						
6.1 COMMON ALARMS						
80	Group alarm 81 - 88	0 1 - 255	No alarms Check 81 - 88			
85	Sensors power supply fault	Clr PS.Ft	No fault Fault			
88	All faulty, deselected or disconnected	Clr SEn.F	No fault Fault			
6.2 CHANNEL ALARMS						
A general form of item number is shown below. The "c" shown in each item number should be replaced by the channel number (1-4). This sequence covers item numbers (101 -499) for channels 1 - 4.						
c90	Group alarm 81 - 88	0 1 - 255	No alarms Check 91 - 94			
c91	High level alarm	Clr Hi.L	No fault Fault			
c92	Low level alarm	Clr Lo.L	No fault Fault			
c93	Sensor fault	Clr S.ft	No fault Fault			
7. DIAGNOSTIC & TEST FUNCTIONS						
10	Processor alarms (11 - 17)	0 1 - 255	No alarms Check 11 - 17			