



TYPE 'IF2'
COMPRESSOR
INTERFACE
(NOTE 5)

- NOTES
- INPUT STATES AS FOLLOWS:-
CLOSED CONTACT = RUNNING READY
or FAULT
OPEN CONTACT = NOT RUNNING, NOT READY
or NO FAULT
 - CON3 TERMINAL 9 MUST HAVE
NEUTRAL CONNECTED TO IT.
 - TO ENSURE THAT INTERNALLY FITTED
SUPPRESSORS WORK CORRECTLY, CONNECT
LINE VOLTAGES TO TERMINALS PREFIXED
'LN' AND THE CORRESPONDING LOADS TO
TERMINALS PREFIXED 'LD'.
 - SWITCH SETTINGS
THE POSITION OF THE DIP SWITCHES 'SW2'
MUST BE SET AS SHOWN (IE: DOT SHOWING
CLOSED CONTACT ON SECOND FROM LEFT)
FOR THE CARD TO OPERATE CORRECTLY.

SWITCHES 'SW3' CONTROL THE OUTPUT
RELAYS IF PACK SERIAL DATA BUS
COMMUNICATIONS FAIL. (CLOSED 'DOT'
SHOWING' = RELAY ENERGISED).
 - IF2-2 SHOWN, IF2-1 HAS NO UNLOAD
RELAY.

JTL SYSTEMS LTD.
41, KINGFISHER COURT, HAMBRIDGE RD,
NEWBURY, BERKSHIRE, RG14 5SJ
TEL: 01635-263646 FAX: 01635-263647

ISSUE	DESCRIPTION	APP'D	DATE
4	UPDATED CHANGED VOLTAGE	MJK	7/97
3	REDRAWN NOTES ADDED	NMT	5/91

TITLE: COMPRESSOR INTERFACE WIRING
(FOR CPxx CONTROLLERS)
TYPE: IF-1 & IF-2

PRD.J.	DRG No.	SHT	OF	ISS.
CP	00120	1	1	4