



NOTE
 THE SWITCHES SW1 & SW2 SET THE INTERFACE FUNCTIONALITY
 SEE THE RELEVANT APPLICATION DRAWINGS FOR THE CORRECT SETUP.

- NOTES**
- INPUT STATES ARE AS FOLLOWS:-
 CLOSED CONTACT = ON
 OPEN CONTACT = OFF
 - CON3 TERMINAL 9 MUST HAVE NEUTRAL CONNECTED TO IT.
 - TO ENSURE THAT INTERNALLY FITTED SUPPRESSORS WORK CORRECTLY, CONNECT LINE VOLTAGES TO TERMINALS PREFIXED 'LN' AND THE CORRESPONDING LOADS TO TERMINALS PREFIXED 'LD'.
- SWITCH SETTING**
- SWITCHES 'SW3' CONTROL THE OUTPUT RELAYS IF PACK SERIAL DATA BUS COMMUNICATIONS FAIL. (CLOSED 'DOT SHOWING' = RELAY ENERGISED).

JTL SYSTEMS LTD.
 41 KINGFISHER COURT, HAMBRIDGE RD,
 NEWBURY, BERKSHIRE, RG14 5SJ
 TEL: 01635-263646 FAX: 01635-263647

ISS	DESCRIPTION	APP'D	DATE
1	ORIGINAL ISSUE	MJK	11/02

TITLE: **PLANT INTERFACE CONNECTIONS**

TYPE: **IF-1**

PROJ.	DRG No:	SHT	OF	ISS.
CP/EP	02880	1	1	1

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP