



NOTES:

1. THE DEFROST AND AUXILLIARY HEATER OUTPUTS ARE CHANGEOVER CONTACTS. SELECT THE APPROPRIATE OUTPUT FOR THE APPLICATION.
2. TO MEET EMC REQUIREMENTS THE CONTROLLER MUST BE INSTALLED ACCORDING TO THE INSTALLATION REQUIREMENTS SHEET FOR THIS PRODUCT.
3. THE LCNS CONTROLLER MUST BE EARTHED TO THE CHASSIS VIA THE CONTROLLER FIXING HOLE AS SHOWN.
4. INPUTS REQUIRE 'C' CONNECTED TO NEUTRAL AND THE INPUT TO 230Vac WHEN SIGNAL IS PRESENT.
5. PLANT INPUTS TO CON B MUST BE ON THE SAME PHASE AS THE SUPPLY ON CON A.
THIS UNIT IS NOT RATED FOR 415V
6. THE DEFROST OUTPUT CAN BE USED FOR DEFROST TERMINATION OR DEFROST CONTROL (SEE ITEM 76 DETAIL IN MANUAL).
7. THE FAN/HEATER OUTPUT RELAY(S) CAN BE SELECTED FOR FAN AND OR HEATER CONTROL (SEE ITEM 104 DETAIL IN MANUAL).
8. INPUTS SHOWN AS AT VERSION 3 FIRMWARE (SWAPPED PREVIOUS TO THAT)

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

JTL SYSTEMS LTD. 41 KINGFISHER COURT, HAMBRIDGE RD, NEWBURY, BERKSHIRE. RG14 5SJ TEL: 01635-263646 FAX: 01635-263647			
ISS	DESCRIPTION	APP'D	DATE
3	ADDED NOTE FOR LCD DISPLAYS	MJK	11/00
5	ADDED NOTE 8	MJK	5/04
4	ADDED NEW DRG NO FOR SENSOR CONNECTIONS	MJK	6/02
TITLE: CABINET CONTROLLER & ASSOCIATED PARTS			
TYPE: LCNS			
PROJ.	DRG No:	SHT	OF
LC	01991	1	1
			ISS.
			5