


**NOTES:**

1. THE DEFROST OUTPUT HAS CHANGEOVER CONTACTS. SELECT THE APPROPRIATE OUTPUT FOR THE APPLICATION.
2. THE LAPE CONTROLLER MUST BE EARTHED TO THE CHASSIS VIA THE CONTROLLER FIXING HOLE AS SHOWN.
3. TO MEET EMC REQUIREMENTS THE CONTROLLER MUST BE INSTALLED ACCORDING TO THE INSTALLATION REQUIREMENTS SHEET FOR THIS PRODUCT.
4. INPUTS REQUIRE 'C' CONNECTED TO THE NEUTRAL AND THE INPUT TO 230Vac WHEN SIGNAL IS PRESENT.
5. PLANT INPUTS TO CON B MUST BE ON THE SAME PHASE AS THE SUPPLY ON CON A.  
THIS UNIT IS NOT RATED FOR 415V
6. FANS/HEATER OUTPUT SELECTABLE USING MAINTENANCE UNIT.

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

 <b>JTL SYSTEMS LTD.</b> 41 KINGFISHER COURT, HAMBRIDGE RD, NEWBURY, BERKSHIRE, RG14 5SJ TEL: 01635-263646 FAX: 01635-263647		ISS		DATE
		DESCRIPTION		APP'D
1		ORIGINAL ISSUE	MJK	02/04
TITLE: CABINET CONTROLLER & ASSOCIATED PARTS SCHEMATIC				
TYPE: LAPE				
PROJ.	DRG No:	SHT	OF	ISS.
LA	03048	1	1	1